



GAS SPRING POWERLINE MOUNTING VARIATIONS


2480.007.05000




2480.008.05000³⁾




2480.010.05000.160³⁾




2480.011.05000




2480.011.05000.2




2480.022.05000




2480.044.05000²⁾




2480.044.03.05000²⁾




2480.045.05000²⁾




2480.047.05000²⁾




2480.055.05000



2480.057.05000



2480.064.05000⁴⁾



Note:

- ²⁾ Attention:
The spring force must be absorbed by the stop Surface!
- ³⁾ Not for use with composite connection.
- ⁴⁾ Square collar flange, non-rotating, fixing for composite connection.
- ⁵⁾ Machine screws with hexagonal socket (compact head recommended)