



# Gas spring POWERLINE

## Mounting variations


2480.007.00750 




2480.008.00750 <sup>3)</sup> 




2480.010.00750.115 <sup>3)</sup>   
2480.010.00750.190 <sup>3)</sup> 




2480.022.00750 




2480.044.00750 <sup>2)</sup> 




2480.044.03.00750 <sup>2)</sup> 




2480.045.00750 <sup>2)</sup> 




2480.047.00750 <sup>2)</sup> 




2480.055.00750 



2480.057.00750 



2480.064.00750 <sup>4)</sup> 



**Note:**

- <sup>2)</sup> Attention:  
The spring force must be absorbed by the stop Surface!
- <sup>3)</sup> Not for use with composite connection.
- <sup>4)</sup> Square collar flange, non-rotating, fixing for composite connection.
- <sup>5)</sup> Machine screws with hexagonal socket (compact head recommended)