



Gas spring POWERLINE

Mounting variations


2480.007.01500




2480.008.01500³⁾




2480.010.01500.130³⁾
2480.010.01500.205³⁾




2480.022.01500




2480.044.01500²⁾




2480.044.03.01500²⁾




2480.045.01500²⁾




2480.047.01500²⁾




2480.055.01500



2480.057.01500



2480.064.01500⁴⁾



Note:

- 2) Attention:
The spring force must be absorbed by the stop surface!
- 3) Not for use with composite connection.
- 4) Square collar flange, non-rotating, fixing for composite connection.
- 5) Machine screws with hexagonal socket (compact head recommended)